

# The Next Generation of Porcelain Furnaces

Pro 200 - ProPress 200

Advanced Technology

**NEW**

The Pro 200 and the Pro Press 200 Porcelain Furnaces are affordable yet intelligently designed with cutting edge technology. They have advanced cycles for e.max®, In-Ceram®, Wol-Ceram®, Captek™, sintered alloys and advanced porcelain products. The Pro 200 Series is completely lead free in compliance with the international RoHS directive.

All Pro Series Porcelain Furnaces come standard with a Vacuum Pump and a 3-Year Warranty or 3,750 muffle hours on unit (US & Canada only). Should the unit ever need servicing, direct access to a service technician is provided, greatly reducing the turnaround time on repairs.

So, when you buy Whip Mix Porcelain furnaces, you can be sure you're making an investment in the long-term success of your laboratory.

**Pro 200**  
furnaces



more reasons. one source

ProPress 200  
Pressing Porcelain Furnace



Pro 200  
Porcelain Furnace



## The Pro 200 Series Features:

- 200 open programs for Pressing or Ceramics.
- Pro 200 Master Suite Software enables user to create and adjust programs from a PC
- Selection knob with built-in enter switch allows for faster, convenient navigation and program entry.
- Transfer programs and upgrades with a standard Flash Drive (included).
- Large 4 line 20 characters LCD display.
- ProPress 200 accommodates 100, 200, and 300 gram rings for more flexibility.
- Patented Quick-Cool Jet
- Factory set 3 point temperature calibration for unsurpassed accuracy.
- 2 stage firing cycles for e.max®.
- Upgraded Thermocouple for improved temperature stability.

Item No.  
93005  
92005

Description  
Pro 200 (120 V ± 10% 50/60Hz)  
Pro Press 200 (120 V ± 10% 50/60Hz)

For more information call 800.626.5651 or visit [www.whipmix.com](http://www.whipmix.com)